




Skylight Guard XL



1. Partially assemble skylight frame as shown in Fig. 1 tighten all setscrews and torque to 29 lb-ft.






3. Assemble remaining parts shown in Fig. 2 tighten all setscrews and torque to 29 lb-ft. **CAUTION: Extreme care should be taken when installing 52" pipes, do not drop them on the skylight dome. Tighten setscrews for 52" pipes on pre-assembled side of frame so they do not fall out.**

INSTALLATION INSTRUCTIONS



Skylight Guard XL




- Check for any loose or missing fasters, tighten or replace as needed.
- Check for damage to wire cage, replace if bent or corroded.

INSTALLATION INSTRUCTIONS CONTINUED



ANNUAL INSPECTION PROCEDURE

Skylight Guard XL Extension Kit



SKYLIGHT GUARD XL EXTENSION KIT EXPLODED VIEW

PARTS LIST



- 2. Build out the Skylight Guard XL Extension Kit one leg section at a time and connect with 52" pipes.
- 3. Be sure to tighten setscrews on fittings with 52" pipe extensions but do not torque at this time.
- CAUTION: Extreme care should be taken when installing 52" pipes, do not drop them on the skylight dome.
- 4. Reconnect XL end assembly to extension kit and torque all setscrews to 29 lb/ft.
- 5. Place all mesh screens in place and attach securely with U-bolts. Tighten U-bolt nuts alternating back and forth until mounting bar bends and nuts are tight.



ANNUAL INSPECTION PROCEDURE

Skylight Guard XL Extension Kit

- Check for any loose or missing fasters, tighten or replace as needed.
- Check for damage to wire cage, replace if bent or corroded.



www.tremcoroofing.com 3735 Green Road Beachwood, Ohio 44122 1.800.852.6013

50 Beth Nealson Drive Toronto, Ontario M4H 1M6 1.800.668.9879