



NOTES

1. PRIME ALL METAL SURFACES WITH APPROVED PRIMER.
2. INSTALL FLASHING SHEET IN APPROVED MASTIC AND STRIP-IN WITH APPROVED ADHESIVE.
3. PRIMING OF THE SUBSTRATE MAY BE REQUIRED, FOLLOW SPECIFICATIONS AND MANUFACTURER RECOMMENDATIONS.
4. REMOVE EXISTING FLASHINGS PRIOR TO INSTALLATION OF NEW FLUID APPLIED SYSTEMS.



SHEET TITLE: ROOF DRAIN LIQUID APPLIED PLUS SYSTEM	SCALE: NTS
	DWG NO. LA-PR-24