



NOTES:

1. THIS TWO PIECE DESIGN MUST BE USED WHEN INSTALLING THE SPECIFIED MEMBRANE.
2. MEMBRANE MUST EXTEND MINIMUM 1" BEYOND THE BOLT HOLES.
3. FIELD WELD MUST NOT PASS UNDER THE CLAMPING RING.
3. THE CLAMPING RING MUST PENETRATE THE MEMBRANE.
4. ALL METAL SURFACES SHALL BE PRIMED BEFORE CONTACT WITH ANY ADHESIVE OR MASTIC.



SHEET TITLE:

DRAIN DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 15