



NOTE:

1. INSTALL SHIMS OR BEVELED WOOD STRIPS TO PROVIDE INWARD SLOPE TO FINISHED COPING CAP