



NOTES

- 1. FASTENERS SHOWN IN THIS DETAIL MAY NOT BE THE FASTENER USED FOR YOUR PROJECT. BE SURE TO USE FASTENERS SPECIFIC FOR YOUR ROOF APPLICATION. FASTENERS SHOWN ARE A REPRESENTATION OF WHAT MAY BE REQUIRED.
- 2. AN APPROVED HIGH TEMP SYNTHETIC UNDERLAYMENT MAY BE USED.
- 3. IF THE SLOPE IS LESS THAN $\frac{3}{2}$, TREMCO INC. REQUIRES A HIGH TEMP SELF-ADHERED UNDERLAYMENT.



SHEET TITLE:

TREMLOCK T-238 HIGH EAVE

SCALE:

NTS

DRAWING No.:

DWG NO. T-238-04