



NOTES

1. FASTENERS SHOWN IN THIS DETAIL MAY NOT BE THE FASTENER USED FOR YOUR PROJECT. BE SURE TO USE FASTENERS SPECIFIC FOR YOUR ROOF APPLICATION. FASTENERS SHOWN ARE A REPRESENTATION OF WHAT MAY BE REQUIRED.
2. AN APPROVED HIGH TEMP SYNTHETIC UNDERLAYMENT MAY BE USED.
3. IF THE SLOPE IS LESS THAN 3/12, TREMCO INC. REQUIRES A HIGH TEMP SELF-ADHERED UNDERLAYMENT.



SHEET TITLE:
TREMLOCK T-238 PLYWOOD DECK
VALLEY

SCALE:
NTS

DRAWING No.:
DWG NO. T-238-92