



- NOTES:**
1. Trim to start and end at building lines.
 2. Attach trim to Support Member with #10-16 x 1" TEK2 Pancake Head at 2'-0" O.C.
 3. Attach panel to framing with #10-16 x 1" TEK2 Pancake Head.

