



- NOTES:**
1. Trim to start and end at window framing.
  2. Attach trim to header with #10-16 x 1" TEK2 Pancake Head at 2'-0" O.C.
  3. Attach panel to framing with #10-16 x 1" TEK2 Pancake Head.

