



NOTES

1. BOTTOM LAYER OF INSULATION SHALL BE LAID DOWN IN A STAGGERED PROFILE. STAGGER AND OFFSET TOP LAYER OF INSULATION FROM BOTTOM LAYER TO PREVENT ALIGNED EDGES.