

## **NOTES**

1. BOTTOM LAYER OF INSULATION SHALL BE LAID DOWN IN A STAGGERED PROFILE. STAGGER AND OFFSET TOP LAYER OF INSULATION FROM BOTTOM LAYER TO PREVENT ALIGNED EDGES.



MULTI-PLY ROOF SYSTEM CROSS SECTION (ADHERED MEMBRANE & INSULATION IN ASPHALT) SCALE:

NTS

DRAWING No.:

**DWG NO. 69**