



NOTES

1. BOTTOM LAYER OF INSULATION SHALL BE LAID DOWN IN A STAGGERED PROFILE. STAGGER AND OFFSET TOP LAYER OF INSULATION FROM BOTTOM LAYER TO PREVENT ALIGNED EDGES.



SHEET TITLE:
 MULTI-PLY ROOF SYSTEM CROSS SECTION
 (MECHANICALLY FASTENED COVER BOARD
 & ADHERED INSULATION)

SCALE:
 NTS
 DRAWING No.:
 DWG NO. 71