



### NOTES

1. BOTTOM LAYER OF INSULATION SHALL BE LAID DOWN IN A STAGGERED PROFILE. STAGGER AND OFFSET TOP LAYER OF INSULATION FROM BOTTOM LAYER TO PREVENT ALIGNED EDGES.



SHEET TITLE:  
**MULTI-PLY ROOF SYSTEM CROSS SECTION (MECHANICALLY FASTENED & ADHERED INSULATION)**

SCALE:  
**NTS**

DRAWING No.:  
**DWG NO. 70**