



NOTES

1. USE TAPERED ROOF INSULATION (EDGE STRIPS) TO CREATE DRAIN SUMP. IF TOTAL INSULATION THICKNESS IS LESS THAN OR EQUAL TO 1 1/2 IN., TAPER 12 IN. FROM THE DRAIN CENTER. IF TOTAL INSULATION THICKNESS IS GREATER THAN 1 1/2 IN., TAPER 18 IN. FROM DRAIN CENTER.



SHEET TITLE:

TYPICAL DRAIN FLASHING WITH
FLEECEBACK MEMBRANE

SCALE:

NTS

DRAWING No.:

DWG NO. 112