



NOTES

1. PLATES & FASTENERS MAY BE USED IN LIEU OF TERM BAR IN NON-PRESSURIZED SITUATIONS.
2. THIS DETAIL NEEDS TO BE USED FOR PRESSURIZED SITUATIONS, IN ALL SYSTEMS.
3. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
4. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES