



NOTES

1. ADD BALLAST PER SPEC FOR BA SYSTEMS.
2. APPLY TPO EDGE SEALANT TO ALL CUT REINFORCED TPO.



SHEET TITLE:

COATED METAL TAPERED EDGE DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 08