



NOTES

1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
2. REMEMBER TO INSTALL UNREINFORCED OR PREMANUFACTURED OUTSIDE CORNERS TO THE SCUPPERS' FOUR ROOF-SIDE CORNERS.
3. SCUPPER MUST BE SEALED OFF ON OUTSIDE OF BUILDING.
4. IF TPO COATED METAL IS NOT AN OPTION ADHERE MEMBRANE TO THE NEW SCUPPER BOX.
5. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES .