

NOTES

- FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
- 2. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

CONCEALED WOOD EQUIPMENT SUPPORT DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 12