



NOTES

1. FOUR CORNER CURB WRAP PIECES ARE NEEDED TO COMPLETE. VARYING SIZES MAY BE NEEDED TO COMPLETE.
2. CORNER WRAP MAY BE ADHERED OR INSTALLED DRY.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES