



NOTES

1. APPLY TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES.



SHEET TITLE:

COUNTERFLASHING
RE-ROOF DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 14