



**NOTES**

1. CLEAN METAL AND MEMBRANE WITH TPO SEAM CLEANER AND ALLOW TO DRY BEFORE PRIMING.
2. PRIME MEMBRANE AND METAL EDGE BEFORE INSTALLING TPO COVER TAPE.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED.



SHEET TITLE:  
COVER TAPE AT METAL DRIP  
EDGE CORNER DETAIL

SCALE:  
NTS  
DRAWING No.:  
DWG NO. 15