



**NOTES**

1. TPO COVER TAPE HEATWELD STRIP ONLY TO BE USED WITH TPO MEMBRANE SYSTEMS ONLY.
2. PRIME THE METAL ONLY WITH TPO PRIMER. DO NOT SPILL PRIMER ON WELDED SEAM AREA.
3. HEAT WELD THE MEMBRANE (NON-ADHESIVE SIDE ONLY) TO MEMBRANE AREA USING EITHER A ROBOTIC OR HAND WELDER TO SPEC.
4. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
5. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES



SHEET TITLE:  
COVER TAPE HEAT WELD STRIP END  
JOINT AT ROOF EDGE DETAIL

SCALE:  
NTS  
DRAWING No.:  
DWG NO. 20