



NOTES

1. CLEAN METAL AND MEMBRANE WITH TPO SEAM CLEANER AND ALLOW TO DRY BEFORE PRIMING.
2. PRIME MEMBRANE AND METAL EDGE BEFORE INSTALLING TPO COVER TAPE.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.
4. APPROVED CAULK GRADE SEALANT SHOULD BE FEATHERED OUT. ENSURE PRIMER EXTENDS UNDER APPROVED CAULK GRADE SEALANT.
5. THIS DETAIL IS NOT TO BE USED ON SLOPES GREATER THAN 1:12.



SHEET TITLE:
COVER TAPE AT ROOF
EDGE CORNER DETAIL

SCALE:
NTS
DRAWING No.:
DWG NO. 16