



NOTES

1. STONE/PAVER BALLAST (NOT SHOWN) REQUIRED FOR BA SYSTEMS.
2. DRAIN PIPE SHALL BE CLEANED SO THAT EXPANDING TAPE SEAL CAN SEAT COMPLETELY AGAINST DRAIN PIPE AFTER RELEASE PAPER HAS BEEN REMOVED.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE: DRAIN - PREFABRICATED TPO DRAIN WITH FLANGE	SCALE: NTS
	DRAWING No.: DWG NO. 26