



STRAINER DOME
 TREMCO WATER BLOCK
 DRAIN FLANGE
 APPROVED FASTENER
 MIN. 4 PER DRAIN
 WOOD NAILER, 5/4" X MIN.
 REINFORCED TPO
 MEMBRANE
 APPROVED ROOF
 INSULATION
 ROOF DECK/SUBSTRATE
 EXISTING DRAIN

NOTES

1. STONE/PAVER BALLAST (NOT SHOWN) REQUIRED FOR BA SYSTEMS.
2. INSTALL RETROFIT DRAIN INTO EXISTING DRAIN PER MANUFACTURERS RECOMMENDATION..
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:
DRAIN - RETROFIT / INSERT

SCALE:
 NTS
 DRAWING No.:
DWG NO. 27