



NOTES

1. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.

EXTEND REINFORCED TPO MEMBRANE ONTO MEMBRANE SECTION POSITIONED AT DRAIN SUMP AND CUT AS SHOWN TO LAY FLAT IN SUMP. HOT AIR WELD A MIN. OF 2" (52 mm) COMPLETELY SURROUNDING AREA.



SHEET TITLE:

DRAIN - SEVERE SUMP TARGET

SCALE:

NTS

DRAWING No.:

DWG NO. 28