



NOTES

1. EXISTING DRAIN PIPE SHALL BE CLEAN OF ALL DEBRIS THE LENGTH OF THE TUBE TO ENSURE PROPER SEAL.
2. EVERGUARD PRE FABRICATED DRAIN CAN ONLY TO BE USED AS A RETROFIT DRAIN.
3. REFER TO PRODUCT APPLICATION INSTRUCTION FOR DRAIN PIPE SECUREMENT.
4. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.