



NOTES

1. T-JOINT PATCH REQUIRED FOR 60, 70 & 80 MIL TPO.
2. FOR HEAT-WELDING LAPS USE 1" MAX (25.4 mm) WELD WITH AUTOMATIC MACHINE WELDER AND 2" WELD WITH HAND WELDER.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

END LAP DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 31