

## **NOTES**

- FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
- APPLY HEAT TO UNREINFORCED DETAIL MEMBRANEAND FORM BY HAND PRIOR TO HOT AIR WELDING.
- APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

FIELD WRAPPED PENETRATION FLASHING DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 41