



## NOTES

1. TO BE USED WHEN TEMPERATURE OF STACK EXCEEDS 160° F.
2. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
3. APPLY HEAT TO DETAIL MEMBRANE AND FORM BY HAND PRIOR TO INSTALLING.
4. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.