

NOTES

- 1. WALL HEIGHTS OVER 10' (3.05 M) HIGH REQUIRE THE ENTIRE WALL TO BE FULLY ADHERED. UNDER 10' (3.05 m) CAN BE DRY HUNG WITHOUT ADHESIVE.
- 2. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

HIGH WALL FLASHING DETAIL 5' (1.25m) WIDE SHEETS

SCALE:

NTS

DRAWING No.:

DWG NO. 44