

## **NOTES**

- 1. ALL SEGMENTS OF THE EAR MUST BE WELDED TOGETHER AND WELDED TO THE WALL
- 2. CHECK SYSTEM SPEC FOR GUIDELINES ON ADHERING FLASHINGS.
- 3. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
- 4. IF TPO MEMBRANE IS USED, BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
- APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

INSIDE CORNER FABRICATION - 2 STEP "PIG EAR" UP DETAIL

SCALE:

NTS

DRAWING No.:

**DWG NO. 49**