



NOTES

1. METAL JOINTS ON THE ROOF SIDE CAN BE CAULKED USING TPO CUT EDGE SEALANT. DO NOT RUN TAPE UP CANTED METAL OF GRAVEL STOP.
2. TPO COVER TAPE TO BE USED ONLY ON TREMPLY TPO MEMBRANE SYSTEMS.
3. TPO COVER TAPE TO BE USED ONLY ON HORIZONTAL SURFACES, NOT TURNED VERTICALLY.
4. TPO COVER TAPE HEAT-WELD USED FOR LONGER GUARANTEES.
5. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

PARAPET WALL WITH METAL EDGE
AND TPO COVER TAPE DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 60