



## NOTES

1. TPO BONDING ADHESIVE NOT NEEDED AND WALL MUST BE PRIMED WITH TPO PRIMER.
2. TPO BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
3. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.