



**NOTES**

1. TPO COVER TAPE HEAT-WELD ONLY TO BE USED WITH TREMPLY TPO MEMBRANE
2. PRIME THE METAL ONLY WITH TPO PRIMER. DO NOT SPILL PRIMER ON WELDED SEAM AREA.
3. HEAT-WELD THE MEMBRANE (NON-ADHESIVE SIDE ONLY) TO MEMBRANE AREA USING EITHER A ROBOTIC OR HAND WELDER TO SPEC.
4. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
5. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES



SHEET TITLE:

COVER TAPE HEAT-WELD STRIP  
OVERLAP AT ROOF EDGE DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 89