



NOTES

1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
2. CLEAN METAL AND MEMBRANE WITH APPROVED TPO SEAM CLEANER AND ALLOW TO DRY BEFORE PRIMING.
3. WHEN ROOF SLOPE IS GREATER THAN 1:12 IN CLIMATES WITH SNOW AND ICE, USE ALTERNATE EDGE DETAIL.
4. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.
5. THIS DETAIL IS **NOT** TO BE USED ON SLOPES GREATER THAN 1:12.



SHEET TITLE:

TREMPLE TPO COVER TAPE
OVERLAP AT ROOF EDGE DETAIL

SCALE:

NTS

DRAWING No.:

DWG NO. 94