



NOTES

1. CLEAN METAL AND MEMBRANE WITH TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIMING
2. TPO COVER TAPE ONLY TO BE USED WITH THE TPO MEMBRANE SYSTEMS.
3. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
4. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.