



# BURmastic® Composite Ply HT

CONTINUED

## Continuous Lay Application:

- Apply cold process adhesive in a uniform and continuous application. Ply shall never touch ply.
- Align the full roll on the underlying ply line.
- Roll out the Composite Ply HT roll into the cold adhesive.
- Broom the Composite Ply HT into place fully and heavily using a 32" wide broom. Do not use a felt rake or squeegee.
- Allow the Composite Ply HT roll to run true; if roll goes off line, cut the ply immediately and reset. Do not attempt to push or stretch roll back onto underlying line.

## Cut and Relax:

- Alternately, the cut and relax method may be used:
- Cut 18' sections of Composite Ply HT and stack the sections for approx. 1 hour.
- Apply cold process adhesive at the recommended coverage rate.
- Align and set the ply using 2 men; 1st man anchors the ply and 2nd man assures the ply is set on line.
- Broom the Composite Ply HT into place fully and heavily, using a 32" wide broom. Do not use a felt rake or squeegee.

**Three ply membrane:** Start and finish roof membrane along edges, terminations, and projections, use starting/finishing strips – 12, 24, and 36" (305mm, 610mm, and 915mm) wide plies.

Install BURmastic Composite Ply HT in shingle fashion. Overlap starter strips 26" (660mm) with first ply, then overlap each succeeding ply 24-2/3" (625mm).

**Four ply membrane:** Start and finish roof membrane along edges, terminations, and projections, use starting/finishing strips – 9, 18, 27 and 36" (229mm, 457mm, 685mm, and 915mm) wide plies.

Install BURmastic Composite Ply HT in shingle fashion. Overlap starter strips 29" (750mm) with first ply, then overlap each succeeding ply 27-1/2" (698mm).

**Base Sheet:** Mechanically attach or embed a full width of BURmastic Composite Ply.

**Side laps:** 4" (100mm). End laps: 6" (150mm) minimum and staggered. Broom plies to assure complete contact. Extend all plies to top edges of all cants and cut off evenly. Overlap previous work 24" (610mm).

Smooth and aggregate surfacing options are available. Consult your local Tremco Representative for specific recommendations.

- BURmastic Composite Ply HT is not intended to perform under ponding conditions. Positive drainage is required.
- BURmastic Composite Ply HT should not be exposed to solvents, oils or other contaminants harmful to asphaltic materials.
- Do not hot apply BURmastic Composite Ply HT in a multi-layer, shingle application.

PROPERTY	TYPICAL VALUE	TEST METHOD
Weight	38 lb/ 100 ft <sup>2</sup> (1.8 g/m <sup>2</sup> )	ASTM D 5147
Thickness	60 mils (1.5 mm)	ASTM D 5147
Tensile strength @ 77°F (25°C)	165 lbf/in (725N) MD, 150 lbf/in (660N) XD	ASTM D 5147
Tensile strength @ 0°F (-18°C)	190 lbf/in (835N) MD, 180 lbf/in (790N) XMD	ASTM D 5147
Tear strength @ 77°F (25°C)	260 lbf MD, 230 lbf XMD	ASTM D 5147
Pliability, 1/2 in.	No failures (13mm) radius	ASTM D 146
Mass of desaturated, mat, min.	3.0 lb/ 100 ft <sup>2</sup> (146 g/m <sup>2</sup> )	ASTM D 228
Surfacing stabilizer, max.	65%	ASTM D 4601
Asphalt	10.0 lb/ 100 ft <sup>2</sup> (485g/m <sup>2</sup> ) minimum	ASTM D 228

# BURmastic® Composite Ply HT

## MAINTENANCE

Your local Tremco Roofing Sales Representative can provide you with effective maintenance procedures which may vary, depending upon specific conditions. Periodic inspections, early repairs and preventative maintenance are all part of a sound roof program.

## PRECAUTIONS

Users must read container labels and Safety Data Sheets for health and safety precautions prior to use.

## TECHNICAL SUPPORT

Your local Tremco Roofing Sales Representative, working with the Technical Service Staff, can help analyze conditions and needs to develop recommendations for special applications.



Roofing & Building Maintenance

[www.tremcoroofing.com](http://www.tremcoroofing.com)

3735 Green Road  
Beachwood, Ohio 44122  
1.800.852.6013

50 Beth Nealson Drive  
Toronto, Ontario M4H 1M6  
1.800.668.9879

Tremco Roofing & Building  
Maintenance is a part of the Tremco  
Construction Products Group

Tremco is a US Registered trademark of Tremco Incorporated.

The information provided on this data page supersedes all previous data concerning this product and its application.

The Statements concerning the materials shown are intended solely as a general guide for material usage and are believed to be true and accurate. Since the manner of use is beyond our control, Tremco DOES NOT MAKE NOR DOES IT AUTHORIZE ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PURPOSE, OR ANY OTHER WARRANTY, GUARANTEE OR REPRESENTATION, EXPRESSED OR IMPLIED, CONCERNING THIS MATERIAL EXCEPT THAT IT CONFORMS TO TREMCO'S PRODUCT SAMPLE. Buyer and user accept the product under those conditions and assume the risk of any failure, injury of person or property and loss or liability resulting from the handling, storage or use of the product, whether or not it is handled, stored, used in accordance with directions or specifications. UNDER NO CIRCUMSTANCE SHALL TREMCO BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM ANY BREACH OF WARRANTY. IN ALL CASES, TREMCO'S LIABILITY IS LIMITED, AT TREMCO'S OPTION, TO THE REPLACEMENT OF GOODS, OR THEIR VALUE, PROVEN TO BE DEFECTIVE IN MANUFACTURING.