

DRAIN STRAINER

CLAMPING RING

TRIM EXISTING FLASHINGS TO WHERE BOWL TURNS DOWN. ENSURE NEW FLASHINGS FULLY ENCAPSULATES OLD FLASHINGS.

DECK CLAMP

EXTEND LIQUID APPLIED SYSTEM INTO DRAIN


CAST-IRON DRAIN BOWL

CLEAN TO BRIGHT METAL AND PRIME

LIQUID APPLIED REINFORCED FLASHING (SPUD GRAVEL PRIOR TO INSTALLING NEW REINFORCED FLASHING)

EXISTING INSULATION SUMP

EXISTING ROOF MEMBRANE (GRAVEL NOT SHOWN FOR CLARITY)



CUT REINFORCEMENT INTO TRIANGLES AND OVERLAP INTO BOWL.

LIQUID APPLIED TOP COAT

LIQUID APPLIED BASE COAT

LIQUID APPLIED LEVELING COAT

NOTES

1. PRIMING OF THE SUBSTRATE MAY BE REQUIRED, FOLLOW SPECIFICATIONS AND MANUFACTURER RECOMMENDATIONS.
2. REINFORCEMENT MUST BE FULLY SATURATED OR ENCAPSULATED IN BASE COAT AS DESCRIBED IN SPECIFICATIONS.
3. REMOVE EXISTING FLASHINGS PRIOR TO INSTALLATION OF NEW FLUID APPLIED SYSTEMS.
4. THE EXISTING LOOSE GRAVEL MUST BE REMOVED AND THE ROOF MUST BE REPAIRED PER MANUFACTURER REQUIREMENTS PRIOR TO APPLICATION OF THE LEVELING COAT.



SHEET TITLE:

ROOF DRAIN GRAVEL
BUR RESTORATION

SCALE:

NTS

DRAWING No.:

DWG NO. LA-GR-24