



SHEET-METAL GUTTER—THE FRONT OF THE GUTTER SHOULD BE A MIN. 1" LOWER THAN THE BACK TO ALLOW OVERFLOW. SEE THE ARCHITECTURAL METAL FLASHING SECTION OF THE NRCA ROOFING MANUAL: ARCHITECTURAL METAL FLASHING, CONDENSATION AND AIR LEAKAGE CONTROL, AND REROOFING FOR OTHER GUTTER SHAPES.

### NOTES

1. GUTTER BRACKETS ARE RECOMMENDED TO BE AT LEAST ONE GAUGE HEAVIER THAN GUTTER STOCK.
2. PRIMING OF THE SUBSTRATE MAY BE REQUIRED, FOLLOW SPECIFICATIONS AND MANUFACTURER RECOMMENDATIONS.
3. REINFORCEMENT MUST BE FULLY SATURATED OR ENCAPSULATED IN BASE COAT AS DESCRIBED IN SPECIFICATIONS.



SHEET TITLE:  
**GUTTER WITH PERIMETER EDGE  
 METAL FULLY REINFORCED  
 RESTORATION**

SCALE:  
 NTS  
 DRAWING No.:  
**DWG NO. LA-FR-27**