



**NOTES**

1. A FIELD WELD CANNOT PASS WITHIN 9" (229 mm) OF THE CLAMPING, OR WITHIN THE DRAIN SUMP ITSELF.
2. MEMBRANE MUST EXTEND MINIMUM 1" (25.4 mm) BEYOND THE BOLT HOLES; THE CLAMPING RING BOLTS MUST PENETRATE THE MEMBRANE.
3. TAPER INSULATION TO CREATE A ROOF SUMP MINIMUM 36" x 36" ( 0.914 m x 0.914 m) IN SIZE (OPTIONAL).
4. IF ASPHALT OR ASPHALTIC PRODUCT IS PRESENT, STOP AT BEGINNING OF SUMP AND FLASH WITH SMOOTH TPO.
5. DO NOT RUN SEPARATION SHEET INTO BOWL AREA IF USED IN SYSTEM.
6. APPLY TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES.



SHEET TITLE:

DRAIN - PRE TARGET

SCALE:

NTS

DRAWING No.:

DWG NO. 25