



NOTES

1. A FIELD WELD CANNOT PASS WITHIN 9" (227 mm) OF THE CLAMPING, OR WITHIN THE DRAIN SUMP ITSELF.
2. MEMBRANE MUST EXTEND MINIMUM 1" (25.4 mm) BEYOND THE BOLT HOLES. THE CLAMPING RING BOLTS MUST PENETRATE THE MEMBRANE.
3. TAPERED INSULATION TO CREATE A ROOF SUMP MINIMUM 36" (0.914 m) x 36" (0.914 m) IN SIZE. (IF APPLICABLE)
4. USE ONE FULL TUBE OF APPROVED CAULK GRADE SEALANT OR TREMCO WATER BLOCK PER DRAIN.
5. ASPHALT OR STONE PAVER MUST STOP AT DRAIN TAPER.